

---

# PIPO

## S1 User Manual Tablet Android 4.1



---

Welcome .....	3
Important Notices .....	3
Keys and Functions .....	4
I. Getting Started .....	5
1.1 Turn on/off.....	5
1.1.1 Turn on.....	5
1.1.2 Turn off.....	5
1.2 Lock/unlock the screen (sleep mode) .....	5
1.3 Connect to computer.....	5
II. Your Home Screen.....	6
2.1 Change wallpaper for home screen:.....	7
2.2 Add/delete applications on home screen: .....	7
2.3 Add widgets to home screen:.....	7
III. Network Connection.....	7
3.1 Wi-Fi.....	7
3.1.1 Turn on Wi-Fi.....	8
3.1.2 Turn off Wi-Fi.....	8
3.1.3 Add a Wi-Fi network .....	8
IV. Internet Browsing .....	9
4.1 Internet Browsing.....	9
V. Install and Manage Apps.....	9
5.1 Install Apps .....	9
5.2 Manage Apps .....	10
VI. Multi-media Functions .....	10
6.1 Music.....	10
6.2 Video .....	11
6.3 Gallery .....	12
6.4 Camera .....	13
6.5 E-book reader .....	13
VII. Settings.....	14
VIII. Explorer .....	16
IX. Battery.....	17
Troubleshooting .....	18

---

## Welcome

Thank you for purchasing this tablet.

It brings you much convenience for your business (supports Word, Excel, send & receive e-mails...) and entertainment (supports 3D game, chatting, movie playback, e-Books.....).


Running on **Android 4.1**, with a 1.6 GHz dual core processor and highly responsive capacitive touch screen, it brings you wonderful user experience.

Before beginning, please refer to this user manual carefully.

## Important Notices

- ⊙ The new battery will be in its best condition after 2-3 times full charge and discharge.
- ⊙ While using the earphone, if the volume is excessively high it may cause hearing damage. So please adjust the volume of the player to a moderate level and balance the time of using.
- ⊙ Do not disconnect the tablet suddenly when formatting or uploading and downloading, which can lead to program errors.
- ⊙ Do not dismantle the tablet by yourself, and do not use alcohol, thinner or benzene to clean its surface.
- ⊙ Do not use the tablet while driving or walking.
- ⊙ The tablet is not moisture and water resistant. Please do not use it in a damp environment.
- ⊙ Do not drop or hit it to hard surface, or the screen may get damaged.
- ⊙ Do not upgrade the firmware by yourself. This would cause damage to your tablet.

## Keys and Functions



1. Front camera	0.3M front camera
2. USB& USB host port	By OTG cable connected, you can connect the device to mouse, keyboard, USB flash disk, USB Lan, USB 3G dangle etc. Connect to a computer via a USB cable to transfer data
3. HDMI out put	Connect device with HDMI cable.
4. Power jack (DC input)	Connect to a 5V output adaptor if included in the accessories.
5. Power and lock key	Hold and press to turn on or turn off this unit. Briefly press to turn on or turn off the screen.
6. TFcard slot	To insert your micro SD card
7. Vol+&Vol-	Press to increase or decrease the volume
8. Reset hole & MIC	Press to reset the tablet if it freezes or behaves abnormal. (Use a paperclip or other sharp object to stab this reset hole, and then press power button to turn it on.)
9. Earphone jack	To connect your earphone
10. Speaker	Speaker


---

## I. Getting Started

### 1.1 Turn on/off

#### 1.1.1 Turn on

To start your tablet, press and hold the power key at the right side of your tablet for a while. Tap and drag the lock out of the circle to unlock.



Tab and drag the lock  out of the circle to unlock.

Drag the lock to right: you will go to the home screen.

Drag the lock to left: you will go to camera directly.

#### 1.1.2 Turn off

To power off your tablet, press and hold the power button until the "Do you want to shut down?" dialog appears and tap "OK" to power it off.

### 1.2 Lock/unlock the screen (sleep mode)

To save battery, you should put your tablet in sleep mode by turning off the LCD display. To do this, shortly press the power key. Press it again to wake up the screen.

### 1.3 Connect to computer

You can connect your tablet to your computer with the supplied USB cable so you can transfer media files.

If your computer is XP system, please install a Windows Media Player 11 for your computer before transfer media files as android 4.1 system needs Windows Media Player 11 support.

## II. Your Home Screen



a. Google search	Tap to enter Google search page
b. Voice search	Tap to open voice search
c. All apps Launcher	Tap to show all the applications installed
d. ESC key	Tap to return to the previous screen/ page.
e. Home	Tap to return to your home page
f. Recent operations	Tap to show your recent operations
g. Screen shot Key	Make screen shot here
h. Vol-	Touch here to decrease Vol
i. Vol+	Touch here to increase Vol
j. Time	Show the time
k. Battery	Show the battery status

---

## 2.1 Change wallpaper for home screen:

Tap and hold your finger in any blank space of the home screen, you will see a pop-up options; you can choose wallpaper from Gallery, live Wallpapers or Wallpapers.

## 2.2 Add/delete applications on home screen:

There are several apps in the home screen, you can also add more frequently-used app icons in this home page and delete some less frequently-used ones.

Tap the app launcher in the top right corner to go to all apps panel, tap and move the app you want to the home screen.

To delete an app from home screen, tap and hold it, and then move it to the remove  icon.

## 2.3 Add widgets to home screen:

Tap all Apps launcher → Tap WIDGETS. There are Analog clock, bookmarks, calendar, Email, and lots of other widgets. Drag the widget you want to the home screen.

Tips: Besides your home screen, you can access to other four panels by sliding left or right in your home screen. You can also customize these panels.

## III. Network Connection


### 3.1 Wi-Fi

Wi-Fi can only be used when it connects with home Wi-Fi Access Point (AP) or a free unsecured Wi-Fi hotpot. Under "Wireless & networks", tap "Wi-Fi" to turn it on. After a moment, your Wi-Fi networks list should populate. If you need to rescan for available networks, tap "scan"

---

### 3.1.1 Turn on Wi-Fi


Within the App Panel, tap “Settings” → then “Wireless & networks” → “Wi-Fi” to turn on wifi.



Your tablet lists the networks it finds within range. Tap a network to connect. If necessary, enter Network SSID, Security, and Wireless password, and tap “Connect”. When your tablet is connected to the network, the wireless indicator  appears in the status bar. Waves indicate connection strength.

### 3.1.2 Turn off Wi-Fi

Please turn off Wi-Fi if you're not using it to save the battery. To turn off Wi-Fi, Tap it again.



### 3.1.3 Add a Wi-Fi network

Users may also add a Wi-Fi network under “Wi-Fi settings”. In “Wi-Fi settings”, tap “Add network”. Enter the SSID (name) of the network. If necessary, enter security or other network configuration details. Touch Save.

**Note:** Network status icons turn green  if you have a Google Account added to your tablet and the tablet is connected to Google services, for syncing your Gmail, Calendar events, contacts, for backing up your settings, and so on.

## 3.2 external 3G Network

This tablet supports external 3G network by a 3G dongle. You can connect the 3G dongle to USB port via the USB convertor cable. You can find the convertor cable in the accessories. However, this tablet supports some 3G dangles, but not all dangles. If you need a special dangles to support, please check with the shop before you buy it.


## IV. Internet Browsing

### 4.1 Internet Browsing

Before using your browser, make sure Wi-Fi or internet is connected.

In your app panel, Tap the browser  icon to open your browser.

Tap the address bar, the Android keyboard will appear for your entry of keywords or URL.



Tap the  icon in the top corner of the browser page to open the submenu.

## V. Install and Manage Apps

### 5.1 Install Apps

Go to the "ApkInstaller"  to install and manage your apps. To install an application, follow below steps:


1. Tap to open the 'APKInstaller' → 'Install' → then tap "Internal Memory" or "TF Card". Available .apk files will appear at the right side. Touch the required one to install it.

**Note:** Make sure the .apk file is workable on android 4.1, and the suffix is .apk. e.g. "angrybirds.apk".

In some cases, there may be no icon on in the App Panel after an .apk file is installed. Possible reasons may be that this app is not compatible with your OS or the downloaded .apk file is a broken one so you may need to download a full version.

## 5.2 Manage Apps

Tap to open the 'APKInstaller' → 'Manage'. Tab the app and then you can launch, export, and uninstall it.




You can also go to "AppS" under "Settings" to manage apps.

## VI. Multi-media Functions

### 6.1 Music

After loading your music into your tablet, tap the music icon  to open the music player. You can select songs by Artist, Albums, songs or Play lists. Tap to select. The media player allows you to shuffle, skip, or pause your current selection and even displays the album artwork when available.




Tab  in the bottom line to open a submenu in music playing page.

## 6.2 Video


You can play videos saved in your tablet or TF card. To play, tap Video

 icon to launch the video player:



---

Tap the video you would like to play. Tap the screen to show the video tool bar. You can play back, fast forward, pause your video here. You can also add bookmark for your video, adjust brightness, or set screen ratio here. Here is the toolbar:




With the Wi-Fi on, you are also able to view an on-line video.

### 6.3 Gallery

You can view, show off, and even edit your digital pictures on the tablet's full color, high-resolution display. After loading your media, tap

Gallery  to display your pictures:



Tap the picture you want to display it, and slide right or left to show other pictures.

Tap the menu icon, you can edit, rotate, crop, or set it as wallpaper.


---

## 6.4 Camera



Tap the  icon to open camera. Your tablet is with built in 0.3M front camera. You can take a photo, or a video.

Note: After you power on your tablet, you can go to camera directly by drag the lock to left.




Camera settings

## 6.5 E-book reader

The tablet supports many e-Book formats like PDF, Text, E-Pub, and FB2....



Tap the "e-book"  icon to open e-book shelves. Tap an e-book to open the book and read.



You can page up or page down by sliding your finger right or left.


Tab  or the menu button to check the sub-menus. You can set the font size, Go to Page jump; check your bookmarks, set the auto flip time, etc.

## VII. Settings



Tap the "Settings" icon  to go to settings.

You can check and set wireless networks, sound, display, storage, Battery, Accounts & sync, security, language, date time, about tablet, etc.



**Wi-Fi:** tap "Settings" → "Wireless & networks" to turn on wifi and scan. It will show a list of Wi-Fi networks scanned in range. Choose a strong Wi-Fi network to connect. (You may need to input the password).

**Display:** To set Brightness, Wallpaper, Sleep time-out, Font size here.

**Storage:** Check internal storage here. If you insert a Micro SD card, or USB disk, you can check the total and available space for your Micro SD card or USB disk. Please unmount it to safely remove it.

**Battery:** Check the Battery status here.

**Display:** Tab "Settings" → "Display" to set brightness, screen time-out, etc.

**Language & input:** to set language and keyboard input.


**Backup & reset:** choose to go to submenu "back up my data" and "Factory data reset". If you choose factory data reset, all data from your tablet's internal storage will be erased. Choose this option carefully.

**About Tablet:** To check information about your tablet, such as Model number, android version, etc.

---

## VIII. Explorer

In Explorer , you can manage all your files. You can copy, delete, paste, or rename your files in your Micro SD card, Internal Memory and USB disk.




For example, to copy files from "Internal Memory" to micro "SD card":

- 1, Open "explorer" you will see the above interface
- 2, tab "Internal Memory" to see files in your tablet

3, Tab "Multi"  icon and then select the files you want to edit

4, Tab "Editor"  icon, you will see a pop-up menu, select "copy"



5, tab "Home"  icon in the top left to return to the main interface, select "SD card", Tab "Editor"  icon, you will see a pop-up menu, select "Paste". Files are copied from your tablet to your Micro SD card now.

## IX. Battery



Very Low Battery



Full Battery



Charging Battery

 indicates that the power of Battery is full. When the battery level becomes too low, a prompt comes up to note you to charge your tablet.

While charging, you can check the charging status in the lock screen:



It takes around 5 hours to charge your tablet to full battery. Please use the 5V adaptor.

---

## Troubleshooting

### 1. Can not turn on the tablet

Check the tablet's power level; please charge it before starting it. In case your tablet still cannot be turned on, you may try to reset it

### 2. No sound from earphone

Check if volume is set to '0'. Or earphone may be broken, please change for another one.

### 3. Big noise

Check if there is dust in the earphone or speaker. Check if the file is broken.

### 4. Frozen to any operation

Please use a pin to reset and then restart your tablet.

### 5. Screen drift or unresponsive screen

Reset or re-power on can solve the problem.

### 6. Application not workable

Possible reasons may be that this app is not compatible with your OS or the downloaded .apk file is broken so you may need to download a full version.

### 8. How delete a Google account?

If an account is added, the account is shown in "Accounts & sync" of "Settings", where you may also add another account. To delete an undesired account, go to "Settings" → "Privacy settings" → "Factory data reset". Your tablet's internal storage, downloaded apps, etc. will also be deleted, except the info in your flash memory. Be careful before you carry out this operation.